

## ibml ImageTracDS 1210 configuration

ScanStation: \_\_\_\_\_ Scanner serial number: \_\_\_\_\_

### Software versions

| Item                       | Version       | Comments |
|----------------------------|---------------|----------|
| ClearCount™                | 2.1           |          |
| Microsoft® Windows®        | 10 Pro (1607) |          |
| SoftTrac® ScanDS           | 4.7.0         |          |
| ImageTracDS® 1210 firmware | 03-04-00      |          |
| SoftTrac® Capture Suite    | 4.2.1.532     |          |
| TWAIN Manager              | 6.8.0.104     |          |
| Parm Setup                 | 6.8.0.104     |          |
| DocNetics                  | 5.6.0.131     |          |

### Files

| Item                            | Filename                                      |
|---------------------------------|-----------------------------------------------|
| SoftTrac ScanDS program         | SoftTracScanDS4.7.0.zip                       |
| SoftTrac Capture Suite          | SoftTracCaptureSuite_4.2.1.532.zip            |
| DocNetics program               | SoftTrac Capture Suite DocNetics-5.4.1.77.zip |
| Clear Ballot license file       | clearballot.lic                               |
| Clear Ballot job file           | Clear Ballot 1210.jobx                        |
| Clear Ballot parm file          | ClearBallot.prmx                              |
| Clear Ballot-certified RXD file | ibml_Duplex_Portrait_200_Gray_None_ED_HSS.rxd |
| Tabulator command file          | IBMLTabulator1210.cmd                         |

## Image settings, density

| Item                                   | Original setting | Current setting |
|----------------------------------------|------------------|-----------------|
| Density (Standard, Simple or Detailed) | Detailed         |                 |
| Simple (Dark, Normal or Light)         | NA               |                 |
| Detailed (Highlight, Shadow and Gamma) |                  |                 |
| Highlight                              | 96               |                 |
| Shadow                                 | -8               |                 |
| Gamma                                  | 130              |                 |

## Front image capture settings, Rear image capture settings

| Item                | Original setting | Current setting |
|---------------------|------------------|-----------------|
| Window 1 Image Type | Grayscale JPG    |                 |
| DPI                 | 200 dpi          |                 |
| Rotate              | 0°               |                 |
| Q-Factor            | 2                |                 |

## Other settings

| Item | Value |
|------|-------|
|      |       |
|      |       |
|      |       |
|      |       |
|      |       |
|      |       |
|      |       |
|      |       |

## Notes

